

Symbol of Quality & Performance

Operating Instructions for Charging Kyoto Japan Batteries

1-Have a look at the battery



2-Remove the Top sticker



Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland

Telephones: +41.21. 826 11 77

Emails: geneva@kyotojap.com & sales@kyotojap.com Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan

www.kyotojap.com



Symbol of Quality & Performance

3-Remove the caps



4-Have a look at the level





Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 11 77

Emails: geneva@kyotojap.com & sales@kyotojap.com Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan

www.kyotojap.com



Symbol of Quality & Performance

5-Check the density



6-Be ready for charging





Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 11 77

Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan www.kyotojap.com



Symbol of Quality & Performance

7-Plug the cables of charger to the terminals of the battery



7-Switch the charger on setting the knob of the first regulation to position 1, Then, the power light will switch on







Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 11 77

Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan www.kyotojap.com



Symbol of Quality & Performance

8-Switch the knob of second regulation to 6



9-Switch the knob of third regulation to 4





Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 11 77

Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan www.kyotojap.com



Symbol of Quality & Performance

10- Verify the amperes pointer goes from 0.5 and 1 A.



...If the pointer is more the 1 amps, decrease the position of the second and third knob regulation 'till the 0.5/1 amps setting is reached.



Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 1177 Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan www.kyotojap.com



Symbol of Quality & Performance

11-Once you get the right setting, switch the timer on and set the time to 2 hours







Symbol of Quality & Performance

12- When this time is over switch the charger off. Then Set the three knobs in the most suitable position for getting about 10-15 amps.....





...register the voltage value and then set the timer to 5/6 hours. Over this period look if there's a voltage increases
VERY IMPORTANT RULE- NEVER go beyond 17 volts



Kyoto Japan Tire (International) S.A

Commercial Office:


1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 1177

Emails: geneva@kyotojap.com & sales@kyotojap.com
Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan
www.kyotojap.com



Symbol of Quality & Performance





Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Swiss VAT No. : CHE-438.476.258 Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland

Telephones: +41.21. 826 1177

Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan www.kyotojap.com



Symbol of Quality & Performance

If the 17 voltage value is reached decrease the amps setting the knobs. Continue like this 'till the amps value reaches 2/3 amps.

Then disconnect the battery and test it on car or with the tester



Kyoto Japan Tire (International) S.A

Commercial Office:

1 Carrefour de Rive, 1207 Geneva – Switzerland Swiss VAT No. : CHE-438.476.258

Registered Office: Faberstrasse 4, 8832 Wollerau – Switzerland Telephones: +41.21. 826 1177

Emails: geneva@kyotojap.com & sales@kyotojap.com

Group Head Office: Kyoto Japan Tire Corporation Ltd., Tokyo - Japan **www.kyotojap.com**